

Key relationships

Modern electrical machines

Calculating torque

Torque is the turning effect of a **force**.

The balance always measures force. This can be related to mass. Force and mass are linked by:

$$\text{Force} = \text{mass} \times \text{acceleration} \text{ or } \mathbf{F = m \times a},$$

where **a** is usually the acceleration due to gravity, 9.81 m/s^2 .

This allows us to calculate the force pressing down on the balance, generated by the dynamometer.

Torque = force x distance from the axis of rotation. It is measured in newton-metres (Nm).

Combining these equations:

$$\text{Torque, } \mathbf{T = m \times a \times r}$$

where, here, **r** is the distance of the pressure point from the centre of the machine.

Putting in the value of **r** for the dynamometer used in this kit:

$$\text{torque (in Nm)} = \text{balance reading (in kg)} \times 9.81 \text{ (m/s}^2\text{)} \times 0.03812 \text{ (m)}.$$

Calculating power

Power is the rate at which energy is delivered and is measured in watts (W).

For a rotating body:

$$\text{Mechanical power} = (2 \times \pi \times \mathbf{n} \times \mathbf{T}) / 60 \quad \text{where } \mathbf{n} \text{ is the speed of the motor in r.p.m.}$$

For a DC motor:

$$\text{Electrical power supplied to the motor} = \mathbf{V_{IN} \times I_{IN}}$$

where **V_{IN}** = input voltage and **I_{IN}** = input current.

For a single phase AC motor:

$$\text{Electrical power supplied to the motor} = \mathbf{V_{IN} \times I_{IN} \times \cos(\Theta)}$$

where **V_{IN}** is the AC rms input voltage, **I_{IN}** is the rms input current

and **cos(Θ)** is the power factor where **Θ** is the phase angle between **V_{IN}** and **I_{IN}**.

For a three phase AC induction motor:

$$\text{Electrical power supplied to the motor} = 3 \times \text{electrical power supplied to one phase}$$

Modern electrical machines

Calculating efficiency

$$\text{Efficiency } (\eta) = (\text{Mechanical power delivered} / \text{Electrical power supplied}) \times 100\%$$

Calculating synchronous speed and slip

$$\text{Synchronous speed in r.p.m} = (f \times 60) / (\text{number of pairs of poles})$$

(Number of pairs of poles relates to how the motor windings are configured:

a 2-pole motor has one pair of poles, a 4-pole motor has two pairs of poles etc.)

$$\text{Slip} = ((\text{synchronous speed} - \text{slip speed}) / \text{synchronous speed}) \times 100\%$$

A three phase supply connected to the stator of an induction machine produces a magnetic field given by the formula:

$$N_s = (f_s/p) \times 60$$

Where f_s = supply frequency and p is the number of pole pairs - in our case 1.

Relationships between three phase star and delta systems

Three phase systems consist of machines connected in star and delta configuration. With U, V and W connections the line voltage is the voltage between any of U, V, W and ground. The phase voltage is the voltage between any two of U, V, W. The line and phase voltage are linked by the equation:

$$V_{\text{line}} = \text{SQRT}(3) \times V_{\text{phase}}$$